

Philips Lid for water container

Twist

Oyster platinum

CRP870

Covers the Senseo Twist water container

Go to the Specifications Tab to check your matching product

This lid covers the water container of your Senseo Twist machine. Easy to remove and clean!

Ease of using Philips spare parts

• Renew your product with original Philips parts



Specifications

Replaceable part
• Fits product type:: HD7872/10, HD7872/11,

HD7872/12

CRP870/01

Highlights

Easy replacement

From time to time your product needs a facelift, and with Philips consumer replacement parts to renew your product, it's never been so easy! All this with guaranteed Philips quality and 1:1 exchange.



Issue date 2013-01-10

Version: 2.0.1

 $\ensuremath{\texttt{©}}$ 2013 Koninklijke Philips Electronics N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com